



- SWPPP NOTES:
1. ALL DISTURBED AREAS NOT PART OF ACTIVE TREAD TO BE STABILIZED WITHIN 7 DAYS OF NOT BEING WORKED. SEE (SWPPP) STORM WATER POLLUTION PREVENTION PLAN FOR DETAILS.
 2. WHENEVER POSSIBLE USE NATIVE DUFF MATERIALS FOUND IN THE TRAIL CORRIDOR AS A MULCH FOR COVERING SOIL EXPOSED BY BACKSLOPE AND DOWNSLOPE CUTS. WOOD CHIPS MADE FROM WOODY MATERIAL CLEARED AS A RESULT OF THE CORRIDOR CLEARING ARE AN ACCEPTABLE ALTERNATIVE TO NATIVE DUFF MULCH.
 3. FOR SLOPE ANGLES UNDER 3:1 USE TEMPORARY EROSION CONTROL SEED MIX AND FOR DISTURBED AREAS THAT ARE LACKING ADEQUATE NATIVE DUFF MATERIAL.
 4. FOR SLOPE ANGLES 3:1 AND OVER USE PERMANENT EROSION CONTROL SEED MIX AND EROSION CONTROL BLANKET FOR LAND SLIDE AREAS AND AREAS OF HEAVY DISTURBANCE. THESE AREAS MUST BE APPROVED BY THE OWNER.
 5. SEE SWPPP FOR SEED MIX DETAILS.
 6. AFTER COMPLETION OF ALL GRADING, THE TRAIL TREAD SHALL BE MECHANICALLY COMPACTED TO ITS SPECIFIED WIDTH USING A VIBRATORY PLATE, SHEEP'S FOOT, OR OTHER APPROVED EQUAL COMPACTOR.
 7. CUT BRUSH AND SLASH MUST BE DISPOSED IN AN UPLAND LOCATION AND MUST BE KEPT OUT OF STREAMS, GULLIES, SWALES, WETLANDS, AND LOW AREAS. SEE SPECIFICATIONS FOR DETAILS.
 8. NO EXCAVATION OR FILL PERMITTED IN WET & LOWLAND AREAS. IT IS THE RESPONSIBILITY OF THE CONTRACTOR TO CONSULT WITH THE OWNER PRIOR TO DOING ANY WORK WITHIN SUSPECTED WET & LOWLAND AREAS.



ROCK CHECK DETAIL


NOT TO SCALE

CONSTRUCTION NOTE:

BACKFILL BEDDING MATERIAL SHALL BE 3"- 6" OF 3/4" - CRUSHED ROCK. THE SAME CRUSHED ROCK CAN BE UTILIZED FOR FILL BETWEEN THE SET ROCK/STONE.



10" MINIMUM ROCK/STONE SET DEPTH.

SEAMS RUNNING IN THE DIRECTION OF TRAVEL SHALL BE MINIMIZED IN BOTH LENGTH AND WIDTH. SEAM WIDTH SHALL BE MINIMIZED AND SEAM STAGGERING SHALL BE USED WHERE POSSIBLE.




TRAIL TREAD ROCK ARMORING AND SIDESLOPE ARMORING DETAIL

NOT TO SCALE



COIR ROLL DETAIL

NOT TO SCALE



WOOD FIBER BLANKET DETAIL

NOT TO SCALE